

IRON WHITE

TPJ 600

Cool Peel Inkjet Transfer Paper

Printing Your Transfer

- Insert a single sheet of transfer paper into the printer with the printable surface loaded correctly for your printer. *(See your printer manual if necessary)*
- For TOP LOADING PRINTERS make sure the notch of the transfer paper is in upper right hand corner.
- For TRAY LOADING PRINTERS the notch will be in the lower right hand corner. Printable surface should be face down.

How To Transfer Using Commercial Heat Press Or Iron

- Cut away blank, unprinted areas of the transfer.
- Place garment onto press pad.
- Place transfer (print side down) onto the garment.
- HEAT PRESS MACHINE – Press the transfer on at 350° F-375°F (medium pressure) for 10 seconds.
- Peel the transfer when hot from fabric using firm, steady pressure.
- HAND IRON-Set your hand iron to the highest heat setting (Cotton/Linen) and let your iron preheat for 10 minutes. Be sure the STEAM setting is OFF.
- Move iron and continuing iron on the whole transfer paper for at least 2 minutes to ensure complete transfer.
- Peel the transfer when hot from fabric using firm, steady pressure.

Washing Instructions

- Machine wash cold only.
- No Bleach.
- Remove promptly from washer and place in dryer. Colors may bleed if garment is wet too long. If bleeding occurs, rewash immediately.
- Dry in dryer on low setting.

ASIA WINNER SDN BHD

NO 7, JALAN BUDI TENGAH 1, TAMAN WAWASAN PERINDUSTRIAN, 83000 BATU PAHAT, JOHOR, MALAYSIA.

Hunting Line : 607-428 9888 (5 LINES) Fax : 607-428 9222

Email : info@asiawinner.com.my

Website: www.asiawinner.com.my