

# JET WHITE

## Hot Peel Inkjet Transfer paper

TPJ 100

### Printing Your Transfer

- Insert a single sheet of transfer paper into the printer with the printable surface loaded correctly for your printer. (See your printer manual if necessary)
- For TOP LOADING PRINTERS make sure the notch of the transfer paper is in the upper right hand corner.
- For TRAY LOADING PRINTERS the notch will be in the lower right hand corner. Printable surface should be face down.

### How To Transfer Using Commercial Heat Press

- Cut away blank, unprinted areas of the transfer.
- Place garment onto press pad.
- Place transfer (print side down) onto the garment.
- Press at 375 degrees F 190°C for 15 seconds, with medium / high pressure.
- Peel when cold to the touch.
- Peel transfer from fabric using firm, steady pressure.

### Washing Instructions



\* Machine wash cold only



\* No Bleach

\* Remove promptly from washer and place in dryer. Colours may bleed if garment is wet too long. If bleeding occurs, rewash immediately



\* Dry in dryer on low setting

### ASIA WINNER SDN BHD

NO 7, JALAN BUDI TENGAH 1, TAMAN WAWASAN PERINDUSTRIAN, 83000 BATU PAHAT, JOHOR, MALAYSIA.

Hunting Line : 607-428 9888 (5 LINES)

Fax : 607-428 9222

Email : [info@asiawinner.com.my](mailto:info@asiawinner.com.my)

Website: [www.asiawinner.com.my](http://www.asiawinner.com.my)