

REFLECTIVE FILM

Cool Peel

APPLICATION INSTRUCTIONS

1. Prepare design as mirror image.
2. Plotter-cut reflective film as mirror image, but not through the clear protective film.
3. Weed and remove the unwanted material.
4. Reflective film can be transferred to 100% cotton, blended cotton & polyester fabrics.

TEMPERATURE

1. Press at 140°C to 10 seconds to tack reflective film to fabric.
 2. Remove the protective clear film from fabric after it has cooled completely.
- NOTE : Test with scrap material prior to actual production.

Storage

1. Storage in a cool, dry place and out of direct sunlight.
2. Should be kept in the original carton.

Care Instructions

1. Reflective film can be hand washed, machine washed or dry cleaned.
2. For the best retention or excellent reflectivity the finished product should be cared for using the following guidelines.

Hand Washing

1. Use a sponge, soft cloth or soft brush moistened with warm water and mild detergents. Rinse thoroughly, dry with a soft cloth or allow to air dry.
2. DO NOT dry in direct sunlight.

Machine Washing

1. For machine washing DO NOT exceed 60°C.
2. DO NOT use strong alkaline or biological detergents. Preferably use neutral detergents with active alkalinity less than 1000ppm and PH below 11.6.
3. DO NOT use bleach.

Dry Cleaning

1. Use a chloric organic solvent, perchloroethylene or trichloroethylene.

Tumble Drying

1. Tumble dry on low heat exceeding 48°C

Important

Reflective film is designed for many applications but user should always carry out trials to assure adequate adhesion to the substrate without causing damage through heat.

ASIA WINNER SDN BHD

NO 7, JALAN BUDI TENGAH 1, TAMAN WAWASAN PERINDUSTRIAN, 83000 BATU PAHAT, JOHOR, MALAYSIA.

Hunting Line : 607-428 9888 (5 LINES)

Fax : 607-428 9222

Email : info@asiawinner.com.my

Website: www.asiawinner.com.my